Date: 20.06.2024 > 1 QUICK REFERENCE GUIDE > DD24DT4NX9

Double DishDrawer Dishwasher, Tall, Sanitize

Contemporary

Stainless Steel



Wash one drawer while you load the other, with room in each drawer for full-size dinner plates.


- · Designed to be installed under your benchtop, with recessed handles for a seamless look
- Six wash programs, as well as additional Quick wash, Sanitize and Extra Dry modifiers
- Flexible racking allows you to customize internal shelves to suit your needs

 Wi-Fi enabled and works with the SmartHQ[™] app for remote control and notifications

DIMENSIONS

Depth

34 - 36 3/8 " Height Width 23 9/16 " 22 9/16 "



FEATURES & BENEFITS

Seamless Fit

Our built-under DishDrawer™ Dishwashers are installed flush under your benchtop with the option of a custom kickstrip. ensuring minimal gaps. The touch-sensitive control panel is located inside this model, leaving an uninterrupted exterior. Designed to match the Fisher & Paykel family of kitchen appliances with recessed handles for a streamlined look.

Ease Of Use

DishDrawer™ Dishwashers are as easy to open and close as kitchen drawers and can be conveniently positioned at bench height for ease of loading and minimal bending. Flexible racking allows you to make adjustments to fit in a variety of dishes.

Quick, Sanitize And Extra Dry Options

The Quick wash modifier delivers a faster wash while maintaining performance. The Sanitize option provides extra protection, killing 99.9% of bacteria* in the final rinse. The Extra Dry setting is perfect for plastic dishes.

True Half Load

Each drawer holds a true half load for small, fast washing that won't waste water. Both drawers operate independently so two wash cycles can operate simultaneously to allow for varying loads.

Knock To Pause

For ease-of-use, these DishDrawer™ Dishwashers have a knock to pause function. A knock on the front panel will pause the dishwasher, which can be restarted by using the start button.

Independent Wash

With the ability to use both drawers independently and select different wash programs, the DishDrawer™ Dishwasher can wash everything from fine glass and crystal to heavily soiled pots and pans.

Quiet Performer

Running at a very low decibel rating, these DishDrawer™ Dishwashers do their job without making a fuss. The combination of intelligent technology and simple mechanics means greater reliability and excellent wash performance.

SPECIFICATIONS

Accessories (included)

QUICK REFERENCE GUIDE > DD24DT4NX9

Cutlery basket	•	Features		Quick	•
Kickstrip	true	Fan assisted drying	•	Sanitise	•
Knife clip and multipurpose clip	•	Flood protection	•	Wash modifiers	3
		Flow through detergent dispenser	•		
		Motor type	BLDC		
Capacity and loading		Quiet operation	•	Wash Programs	
Accommodates round plates up to	12.25" (top) 11" (bottom)	SmartDrive™ technology	•	Delicate Eco	•
Adjustable height, foldable cupracks	•			Fast	•
Fold down tines	•	Doufoumana			•
Pitch adjustable tines	•	Performance		Heavy	•
Place settings	14	Noise on standard cycle top drawer	42 dBA	Medium	•
Place settings	14			Rinse	•
Place settings per drawer	7			Wash programs	6
Place settings per drawer	7	Power Requirements			
		Amperage	10A	Water connection	
		Supply frequency	60Hz		
Consumption		Supply voltage	100 - 120V	Supplied hose to suit 3/8" (9mm) male compression fitting	•
Energy usage	265kWh/year			Water pressure	30kPa - 1000 kPa
In-use energy carbon emissions estimate	97.1kgCO2e/year	Product Dimensions			
Water usage (per wash cycle)	3.28 gal running	Product Dimensions			
	both tubs	Depth	22 9/16 "	CIAL	00001
		Height	34 - 36 3/8 "	SKU	82901
Combuelle		Width	23 9/16 "		
Controls				The product dimensions and specifications in this pag	e apply to the specific
Energy saving delay start option of up to 12 hours	•			product and model. Under our policy of continuous in	
		Warranty		dimensions and specifications may change at any tim- check with Fisher & Paykel's Customer Care Centre to	
Keylock	•	Parts and labor	Limited 2 years	correctly describes the model currently available. $\ensuremath{\mathbb{G}}$ Fisher & Paykel	
Knock to pause	•			Appliances Ltd 2020	
Rinse aid indicator light	•				
Smart appliance	•	Wash Program Modifiers			
Wi-Fi connectivity	•	Extra Dry	•	Other product downloads available at fisherpaykel.com	

QUICK REFERENCE GUIDE > DD24DT4NX9 Date: 20.06.2024 > 3



Energy Label Double DishDrawer™ Dishwasher



Service & Warranty



Installation Guide DishDrawer™ Dishwasher



Guide d'installation FR

Preliminary Specification Guide Double DishDrawer™ Dishwasher



User Guide EN / Guide d'utilisation FR



Wash Program Data DishDrawer™ Dishwasher EN

Where applicable:

All appliances use energy, and energy usage typically generates carbon emissions. Fisher & Paykel Appliances' In-use Energy Carbon Emissions Estimate indicates carbon emissions from a product's in-use energy. This is calculated either annually or per cycle, using the product's market-specific energy label energy consumption data multiplied by the carbon emissions factor for energy in your country or region.

Our In-use Energy Carbon Emissions Estimate is designed to assist customers in making informed purchasing decisions when comparing different Fisher & Paykel products. For example, a heat pump dryer typically has a lower In-use Energy Carbon Emissions Estimate than a vented dryer.



A PEACE OF MIND SALE 24 Hours 7 Days a Week Customer Support

T 1.888.936.7872 Wwww.fisherpaykel.com