QUICK REFERENCE GUIDE > DD24DT4NX9

Series 9, Contemporary Tall Double DishDrawer Dishwasher

Series 9 | Contemporary



Wash one drawer while you load the other, with room in each drawer for full-size dinner plates.


- Designed to be installed under your benchtop, with recessed handles for a seamless look
- Six wash programs, as well as additional Quick wash, Sanitize and Extra Dry modifiers
- Flexible racking allows you to customize internal shelves to suit your needs

 Wi-Fi enabled and works with the SmartHQ[™] app for remote control and notifications

DIMENSIONS

Depth

Height 34 - 36 3/8 "
Width 23 9/16 "



FEATURES & BENEFITS

Seamless Fit

Our built-under DishDrawer™ Dishwashers are installed flush under your benchtop with the option of a custom kickstrip, ensuring minimal gaps. The touch-sensitive control panel is located inside this model, leaving an uninterrupted exterior. Designed to match the Fisher & Paykel family of kitchen appliances with recessed handles for a streamlined look.

Ease Of Use

DishDrawer™ Dishwashers are as easy to open and close as kitchen drawers and can be conveniently positioned at bench height for ease of loading and minimal bending. Flexible racking allows you to make adjustments to fit in a variety of dishes.

Quick, Sanitize And Extra Dry Options

The Quick wash modifier delivers a faster wash while maintaining performance. The Sanitize option provides extra protection, killing 99.9% of bacteria* in the final rinse. The Extra Dry setting is perfect for plastic dishes.

True Half Load

22 9/16 "

Each drawer holds a true half load for small, fast washing that won't waste water. Both drawers operate independently so two wash cycles can operate simultaneously to allow for varying loads.

Knock To Pause

For ease-of-use, these DishDrawer™ Dishwashers have a knock to pause function. A knock on the front panel will pause the dishwasher, which can be restarted by using the start button.

Independent Wash

With the ability to use both drawers independently and select different wash programs, the DishDrawer™ Dishwasher can wash everything from fine glass and crystal to heavily soiled pots and pans.

Quiet Performer

Running at a very low decibel rating, these DishDrawer™
Dishwashers do their job without making a fuss. The
combination of intelligent technology and simple mechanics
means greater reliability and excellent wash performance.

SPECIFICATIONS

Accessories (included)

Cutlery basket	•	Features		Wash modifiers	3
Kickstrip	true	Fan assisted drying	•		
Knife clip and multipurpose clip	•	Flood protection	•		
		Flow through detergent dispenser	•	Wash Programs	
		Motor type	BLDC	Delicate	•
Capacity and loading		Quiet operation	•	Eco	•
Accommodates round plates up to	12.25" (top) 11" (bottom)	SmartDrive™ technology	•	Fast Heavy	•
Adjustable height, foldable cupracks	•			Medium	
Fold down tines	•	Performance		Rinse	
Pitch adjustable tines	•	Performance		Wash programs	6
Place settings	14	Noise on standard cycle top drawer	42 dBA	wasii programs	0
Place settings	14				
Place settings per drawer	7	Dower Dogwirements		Water connection	
Place settings per drawer	7	Power Requirements		Inlat water temperature	May 140 °F
		Amperage	10A	Inlet water temperature	Max 140 °F
		Electric circuit	3	Supplied hose to suit 3/8" (9mm) male compression fitting	•
Consumption		Rated current	15 A	Water pressure	30kPa - 1000 kPa
Energy usage	265kWh/year	Supply frequency	60Hz	Water supply	3/8" to suit Male
In-use energy carbon emissions estimate	93.5kgCO2e/year	Supply voltage	100 - 120V		Compression Fitting
Water usage (per wash cycle)	3.28 gal running both tubs				
		Product Dimensions			
Controls		Depth	22 9/16 "	SKU	82901
		Height	34 - 36 3/8 "		
Energy saving delay start option of up to 12 hours	•	Width	23 9/16 "	The product dimensions and specifications in this page apply to the specific	
Keylock	•			product and model. Under our policy of continuous dimensions and specifications may change at any tire	
Knock to pause	•	Wash Program Modifiers		check with Fisher & Paykel's Customer Care Centre t	
Rinse aid indicator light	•	-		correctly describes the model currently available. © Appliances Ltd 2020	Fisher & Paykel
Smart appliance	•	Extra Dry	•	Appliances Ltd 2020	
		Quick	•		
		Sanitise	•		

QUICK REFERENCE GUIDE > DD24DT4NX9

Other product downloads available at fisherpaykel.com



J. 2D-DXF DishDrawer™ Dishwasher

Energy Label Double DishDrawer™ Dishwasher

↓ Installation Guide (English)

↓ Revit

Rhino

Right To Repair Declaration (English, Canadian French)

↓ SketchUp

↓ User Guide EN / Guide d'utilisation FR

Wash Program Data DishDrawer™ Dishwasher EN

Where applicable:

All appliances use energy, and energy usage typically generates carbon emissions. Fisher & Paykel Appliances' In-use Energy Carbon Emissions Estimate indicates carbon emissions from a product's in-use energy. This is calculated either annually or per cycle, using the product's market-specific energy label energy consumption data multiplied by the carbon emissions factor for energy in your country or region.

Our In-use Energy Carbon Emissions Estimate is designed to assist customers in making informed purchasing decisions when comparing different Fisher & Paykel products. For example, a heat pump dryer typically has a lower In-use Energy Carbon Emissions Estimate than a vented dryer.



A PEACE OF MIND SALE 24 Hours 7 Days a Week Customer Support

T 1.888.936.7872 Wwww.fisherpaykel.com