Double DishDrawer Dishwasher, Tall, Sanitize

Series 9 | Contemporary

Stainless Steel




Doing the dishes got easier. Load one drawer while the other washes - with the top drawer fitting your large dinner plates easily.

- Six wash programs, as well as additional Quick wash. Sanitize and Extra Dry options
- Flexible racking can be folded down to fit bigger dishes

DIMENSIONS





FEATURES & BENEFITS

Ease Of Use

DishDrawer[™] Dishwashers are as easy to open and close as kitchen drawers and can be conveniently positioned at bench height for ease of loading and minimal bending. Flexible racking allows you to make adjustments to fit in a variety of dishes.

Independent Wash

With the ability to use both drawers independently and select different wash programs the DishDrawer[™] Dishwasher can wash everything from fine glass and crystal to heavily soiled pots and pans.

True half load

Each drawer holds a true half load for guilt-free small washes and fast turnaround of your dishes. Both drawers operate independently so different wash cycles can operate simultaneously to accommodate a variety of loads.

Complementary design

DishDrawer™ Dishwashers are designed to match the Fisher & Paykel family of kitchen appliances, with matching handles, premium styling and quality materials for a stylish finish in your kitchen.

Quick, Sanitize and Extra Dry options

The Quick wash modifier delivers a faster wash while maintaining performance. The Sanitize option provides extra protection killing 99.9% of bacteria in the final rinse. The Extra Dry setting is perfect for plastic dishes.

Quiet performer

Running at a very low decibel rating, these DishDrawer™ dishwashers do their job without making a fuss. The combination of intelligent technology and simple mechanics means greater reliability and excellent wash performance.

SPECIFICATIONS

Accessories (included)	
Cutlery basket	•
Kickstrip	true
Knife clip and multipurpose clip	•

Accessories (sold separately)

Handle kit Contemporary square fine, black	AHD5-
	OBDD-60SB

QUICK REFERENCE GUIDE > DD24DDFTX9 N

Capacity and loading

Accommodates round plates up to	12.25" (top) 11" (bottom)
Adjustable height, foldable cupracks	•
Fold down tines	•
Pitch adjustable tines	•
Place settings	14
Place settings	14

Consumption

Energy usage	263kWh/year
In-use energy carbon emissions estimate	96.4kgCO2e/year
Water usage (per wash cycle)	3.28 gal running both tubs

Controls

Electronic fault/Diagnostic indicator
End of cycle beeps
Energy saving delay start option of up to 12 hours
Internal wash selector
Keylock
Rinse aid indicator light
Smart appliance
Wi-Fi connectivity

Fan assisted drying	
Flood protection	

Quiet operation	
SmartDrive™ technology	
Performance	
Noise on standard cycle top drawer	42 0
Power Requirements	
Amperage	
Electric circuit	3
Rated current	
Supply frequency	6
Supply voltage	100 - 1
Product Dimensions	
Depth	22 9/
Height	34 - 36 3
Width	23 9/
Warranty	

Wash Program Modifiers

- Extra Dry
- Quick
- Sanitise

•	Wash modifiers
•	
	Wash Programs
	Delicate
	Eco
42 dBA	Fast
	Heavy
	Medium
	Rinse
10A	Wash programs
3 wire	
15 A	

Water connection

Inlet water temperature	Max 140 °F
Supplied hose to suit 3/8″ (9mm) male compression fitting	•
Water pressure	30kPa - 1000 kPa
Water supply	3/8" to suit Male Compression Fitting

SKU			82343

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. © Fisher & Paykel Appliances Ltd 2020

Date: 09.07.2024 > 2

3

6

FISHER & PAYKEL

Other product downloads available at fisherpaykel.com

- ↓ 2D-DWG Double DishDrawer™ Dishwasher
- ↓ 2D-DXF Double DishDrawer™ Dishwasher
- ↓ Data Sheet Double DishDrawer™ Dishwasher
- ↓ Energy Label Double DishDrawer™ Dishwasher
- Service & Warranty
- J Installation Guide Double DishDrawer™ Dishwasher EN
- Justallation Guide Double DishDrawer™ Dishwasher EN
- ↓ Quick Start Guide DishDrawer™ Dishwasher EN
- ↓ Revit Double DishDrawer™ Dishwasher
- ↓ Rhino Double DishDrawer™ Dishwasher
- ↓ Sketchup Double DishDrawer™ Dishwasher
- ↓ User Guide DishDrawer™ Dishwasher EN

Where applicable:

All appliances use energy, and energy usage typically generates carbon emissions. **Fisher & Paykel Appliances' In-use Energy Carbon Emissions Estimate** indicates carbon emissions from a product's in-use energy. This is calculated either annually or per cycle, using the product's market-specific energy label energy consumption data multiplied by the carbon emissions factor for energy in your country or region.

Our In-use Energy Carbon Emissions Estimate is designed to assist customers in making informed purchasing decisions when comparing different Fisher & Paykel products. For example, a heat pump dryer typically has a lower In-use Energy Carbon Emissions Estimate than a vented dryer.



A PEACE OF MIND SALE 24 Hours 7 Days a Week Customer Support T 1.888.936.7872 Wwww.fisherpaykel.com