

### SAFETY & WARNINGS

**⚠ WARNING!**

**✋ Cut Hazard**  
Failure to use caution could result in injury.

- Take care: some edges may be sharp.

- For products that are not front-mounted, installation must be carried out by a Fisher & Paykel trained and supported service technician.
- Ensure all packaging is removed and disposed of responsibly.
- Installation of this product requires basic mechanical skills.
- Ensure product is installed with the correct tools to avoid personal injury or damage to the appliance.
- Take care not to scratch the door with the supplied Hex key when tightening the screws.

### COMPONENTS REQUIRED

#### Supplied



Handle (1)



M5x25mm countersunk screw (2) for Dishdrawer panels



M5x25mm pan head screw (2) for Custom and Dishwasher panels

#### Not supplied



Powered driver



Crosshead driver



Tape measure




Level

For more information, visit [www.fisherpaykel.com](http://www.fisherpaykel.com)

### FITTING HANDLE TO PANEL

#### CUSTOM PANELS

①



Mark the handle location on the panel. Ensure distance between holes is 432mm.

②



Drill the holes using a 6mm drill bit.  
Counterbore to a maximum depth of 5mm from the back of the panel.

③



Align the handle with the pin holes at the front of the panel.  
Insert the supplied pan head screws from the rear of the panel.  
Secure the handle by tightening the screws using a crosshead driver.

④



Follow the instructions in the install guide to attach the custom panel to the drawer or dishwasher.

#### PRE-FINISHED PANELS

①



Align the handle with the pin holes at the front of the panel (custom or supplied).

②



Insert the supplied screws from the rear of the panel.  
Secure the handle by tightening the screws using a crosshead driver

- For custom and Dishwasher panels, use panhead screws.
- For Dishdrawer panels, use countersunk screws.