

DATA SHEET

680MM ACTIVESMART™ FRIDGE - BOTTOM FREEZER

Model no:
E442BRXFD4, E442BRXFD5
E442BRWFD4, E442BRWFD5

Product Dimensions	mm
Ⓐ Overall height* of fridge	1715
Ⓑ Overall width of fridge	680
Ⓒ Depth of fridge door and gasket (excludes handle)	70
Ⓓ Depth of fridge door and chassis (excludes handle)	695
Ⓔ Depth of fridge chassis (does not include fridge door)	625
Ⓕ Height from bottom datum to top of fridge door	1691
Ⓖ Height of feet (adjustable)	24
Ⓜ Height from bottom datum to bottom of bottom door	17
Ⓢ Height from bottom datum to bottom of bottom handle	245
Ⓣ Height from bottom datum to top of bottom handle	619
Ⓥ Height from bottom datum to top of bottom door	629
Ⓦ Height from bottom datum to bottom of top door	639
Ⓨ Height from bottom datum to bottom of top handle	648
Ⓩ Height from bottom datum to top of top handle	1260
ⓐ Width of handle	15
ⓑ Depth of handle (measured from front of door)	41
Ⓒ Depth of door (open at 90°) (measured from front of door)	628
Ⓓ Rotation of door (open) (measured from front of door)	138°


* Includes mounted feet

Minimum Clearances	mm
Minimum height of cavity	1735
Minimum side clearance installed flush with chassis	20
Side clearance (hinge side) - installed flush with door - full rotation	135
Rear clearance (including evaporator tray)	30


INDICATES PRODUCT DATUM
INDICATES CABINETRY CLEARANCES

DATE: 08.10.2015


IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com



PLAN VIEW



FRONT VIEW



PROFILE VIEW

