



C = 51, M = 0, Y = 9, K = 0



Pantone 2746

Size: 11cm x 14cm

# Water Efficiency



Water Consumption: **4.40 L/kg**

Wash Mode: **COTTONS, 40°C, 1400rpm, ECO**

Type of Product: **Clothes Washing Machines**

Brand: **Fisher & Paykel**

Model: **WH1060P4**

Registration No.: **WM-2024/044787/TUV**



Actual water consumption may vary from test results

**Type of products:  
Clothes washing machine**