QUICK REFERENCE GUIDE > DW24UNT4X2

# Built-in Dishwasher, Tall, Sanitize

Series 9 | Contemporary

Stainless Steel



Offering a superior wash performance and advanced drying, this dishwasher is designed to fit flush under your benchtop for a seamless look.


- Designed to be built under your benchtop, fitting flush with cabinetry for a seamless look
- Eight wash programs from Heavy to Light, including Auto, 60min and Glassware
- Dry+, Sanitize, Half Load and Intensive modifiers provide extra wash options

 Wi-Fi enabled and works with the SmartHQ™ app for remote control and notifications

# **DIMENSIONS**

Depth

Height 33 3/4 - 36 1/8 "
Width 23 1/2 "



# **FEATURES & BENEFITS**

# Seamless Design

Install this dishwasher flush under your benchtop with minimal gaps. Designed to match our Contemporary family of appliances with a recessed handle for a seamless finish in your kitchen.

Advanced Drying

For beautifully dry dishes every time, this dishwasher features an advanced drying system. It combines fan-assisted drying with an automatic door opening at the cycle's end. The Auto Door Open Dry feature releases excess steam, ensuring dishes are immediately ready for use or storage. An innovative air curtain channels the steam away from the adjacent benchtop, protecting your cabinetry.

# An Exceptional Clean

22 5/8 "

This dishwasher offers eight wash programs including Glassware and Auto, which automatically senses the optimal wash settings for your dishes. The three-stage filtration system delivers a superior clean, while the rinse aid indicator reminds you to top up for beautifully clean dishes.

# **Customize Your Wash**

Create the perfect wash with our range of modifiers, from Intensive for a thorough clean to Half Load, ideal for a partial load. The Sanitize modifier provides extra protection, killing 99.9% of bacteria\* in the final rinse, while Dry+ is great for plastic dishes.

\*Certified to NSF/ANSI Standard 184

# **Quiet Performer**

Running at a very low decibel rating, this dishwasher does its job without making a fuss. The combination of clever technology and simple mechanics means greater reliability and superior wash performance, with minimal noise.

#### **Efficient Performance**

With an Energy Star Most Efficient rating, this dishwasher is recognised as among the most energy efficient models on the market. Use the Eco wash program for optimal water and energy consumption, or choose when the cycle begins with Delay Start.

# Flexible Loading

QUICK REFERENCE GUIDE > DW24UNT4X2 Date: 28.06.2024 > 2

Designed to fit 15 place settings, this spacious model lets you stack large items with ease. Adjustable rack options provide flexibility for any load, with a full-width cutlery tray, heightadjustable middle rack, cup holders and wine glass supports.

# **SPECIFICATIONS**

Cutlery basket  Kickstrip  true  Accessories (sold separately)  Handle kit Contemporary square fine, black  Capacity and loading  Accommodates round plates up to (lower basket)  Accommodates round plates up to (top basket)  Adjustable height, foldable cupracks  Easy lift adjustable upper basket  Fold down tines  Full width cutlery/utensil tray  Large crockery insert in lower basket  Place settings  Place settings  Telescopic slides  Wine glass supports with stemware grippers	Accessories (included)	
Accessories (sold separately)  Handle kit Contemporary square fine, black  Capacity and loading  Accommodates round plates up to (lower basket)  Accommodates round plates up to (top basket)  Adjustable height, foldable cupracks  Easy lift adjustable upper basket  Fold down tines  Full width cutlery/utensil tray  Large crockery insert in lower basket  Place settings  15  Telescopic slides	Cutlery basket	•
Handle kit Contemporary square fine, black  Capacity and loading  Accommodates round plates up to (lower basket)  Accommodates round plates up to (top basket)  Adjustable height, foldable cupracks  Easy lift adjustable upper basket  Fold down tines  Full width cutlery/utensil tray  Large crockery insert in lower basket  Place settings  15  Telescopic slides	Kickstrip	true
Handle kit Contemporary square fine, black  Capacity and loading  Accommodates round plates up to (lower basket)  Accommodates round plates up to (top basket)  Adjustable height, foldable cupracks  Easy lift adjustable upper basket  Fold down tines  Full width cutlery/utensil tray  Large crockery insert in lower basket  Place settings  15  Telescopic slides		
Capacity and loading  Accommodates round plates up to (lower basket)  Accommodates round plates up to (top basket)  Adjustable height, foldable cupracks  Easy lift adjustable upper basket  Fold down tines  Full width cutlery/utensil tray  Large crockery insert in lower basket  Place settings  Telescopic slides	Accessories (sold separately)	
Accommodates round plates up to (lower basket)  Accommodates round plates up to (top basket)  Adjustable height, foldable cupracks  Easy lift adjustable upper basket  Fold down tines  Full width cutlery/utensil tray  Large crockery insert in lower basket  Place settings  15  Telescopic slides	Handle kit Contemporary square fine, black	
basket)  Accommodates round plates up to (top basket)  Adjustable height, foldable cupracks  Easy lift adjustable upper basket  Fold down tines  Full width cutlery/utensil tray  Large crockery insert in lower basket  Place settings  15  Telescopic slides	Capacity and loading	
basket)  Adjustable height, foldable cupracks  Easy lift adjustable upper basket  Fold down tines  Full width cutlery/utensil tray  Large crockery insert in lower basket  Place settings  15  Place settings  Telescopic slides		12 9/16"
Easy lift adjustable upper basket  Fold down tines  Full width cutlery/utensil tray  Large crockery insert in lower basket  Place settings  Place settings  15  Telescopic slides		9 13/16"
Fold down tines  Full width cutlery/utensil tray  Large crockery insert in lower basket  Place settings  Place settings  Telescopic slides  •	Adjustable height, foldable cupracks	•
Full width cutlery/utensil tray  Large crockery insert in lower basket  Place settings  15  Place settings  15  Telescopic slides	Easy lift adjustable upper basket	•
Large crockery insert in lower basket  Place settings  Place settings  15  Telescopic slides	Fold down tines	•
Place settings 15 Place settings 15 Telescopic slides •	Full width cutlery/utensil tray	•
Place settings 15 Telescopic slides •	Large crockery insert in lower basket	•
Telescopic slides •	Place settings	15
	Place settings	15
Wine glass supports with stemware grippers •	Telescopic slides	•
	Wine glass supports with stemware grippers	•

Consumption	
Energy rating	Energy star Most efficient
Energy usage	210kWh/year
In-use energy carbon emissions estimate	77.0kgCO2e/year
Water usage (per wash cycle)	3.2 gal
Controls	
Energy saving delay start option of up to 12	•

Energy saving delay start option of up to 12 hours	•
Floor light cycle feedback	•
Internal light	•
Internal wash selector	•
Intuitive capacitive touch controls	•
Keylock	•
Rinse aid indicator light	•
Smart appliance	•
Wi-Fi connectivity	•

Features	
Air curtain for bench protection	•
Auto Door Open Dry	•
Fan assisted drying	•
Flood protection	•
Fully independent spray arms	•
Half load option	•
Internal tub material	Stainless Steel
Motor type	BLDC
Variable wash pressure technology	•
	-

Performance	
Noise emissions	42 dBA
Power Requirements	
Amperage	10A
Supply frequency	50Hz
Supply voltage	100 - 120V
Product Dimensions	
Depth	22 5/8 "
Height	33 3/4 - 36 1/8 "
Width	23 1/2 "
Warranty	
Parts and labor	Limited 2 years
Wash Program Modifiers	
Dry +	•
Half load	•
Intensive	•
Sanitise	•

# Sanitise Wash modifiers

60 min	•
Auto	•

**Wash Programs** 

QUICK REFERENCE GUIDE > DW24UNT4X2

Eco	•
Glassware	•
Heavy	•
Light	•
Medium	•
Rinse	•
Wash programs	8

# Water connection

Water pressure 30kPa - 1000 kPa

SKU 82444

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. © Fisher & Paykel Appliances Ltd 2020

# Other product downloads available at fisherpaykel.com

- ↓ 2D-DWG Dishwasher
- 2D-DXF Dishwasher
- Data Sheet Dishwasher
- Energy Label Dishwasher
- ↓ Service & Warranty
- Installation Guide Built-in Dishwasher
- ↓ Guide d'installation FR
  - Preliminary Specification Guide Dishwasher



User Guide Dishwasher



Guide d'utilisation FR

# Where applicable:

All appliances use energy, and energy usage typically generates carbon emissions. Fisher & Paykel Appliances' In-use Energy Carbon Emissions Estimate indicates carbon emissions from a product's in-use energy. This is calculated either annually or per cycle, using the product's market-specific energy label energy consumption data multiplied by the carbon emissions factor for energy in your country or region.

Our In-use Energy Carbon Emissions Estimate is designed to assist customers in making informed purchasing decisions when comparing different Fisher & Paykel products. For example, a heat pump dryer typically has a lower In-use Energy Carbon Emissions Estimate than a vented dryer.



A PEACE OF MIND SALE 24 Hours 7 Days a Week Customer Support

 ${f T}$  1.888.936.7872  ${f W}$ www.fisherpaykel.com